



Setting up your HP Deskjet 470 Printer

1. Turn on your Pocket PC & your printer (be sure not to forget to plug the wi-fi card into the slot located on the left side of your printer.)
2. On the main screen of the PDA (aka Today screen), locate Ipaq wireless line, and press on the grey box with, "WLAN" written on it.
3. After pressing on the "WLAN" box it will change colors from gray to amber to green, and a screen will appear saying, "Multiple networks detected."
4. Select, "HPsetup" from that screen.
5. Another window will appear asking you what to connect to. The choices will be "Work" or Internet". Select "Work".
6. Place a sheet of paper in the printer, and hold down the silver button on the top of the printer located on the far left, it has an "X" marked on it. Hold down this button for 5-7 seconds
7. An information sheet will print. Scan the page until you see 3 dotted line boxes going across the page, about 3 quarters of the way down the page.
8. Locate the line, "IP Address" (just to the left of the boxes). Follow that line across the page until you see a set of numbers that begin with 169.254....
9. Open Palm-Tech Inspector on your PDA, and open the inspection you want to print.
10. Go to File → Print (located at the bottom left of the screen).
11. The print screen will appear, locate the line the reads "port"
12. Click on the dropdown on the line "port", and select "Network: IP Printer"

How To: Set up your HP Deskjet 470

13. A button titled "Set Printer IP" will appear at the bottom of the screen. Click the box and enter the IP address from the information page. (Be sure to include a period (".") after each set of numbers)
14. Press "Start Printing"
15. Bytes of information will transfer from PDA to printer then a second print screen will appear. Customize the info as you see fit, press ok, and enjoy mobile printing!

If you have any other questions or if anything is unclear give us a call at 1-888-736-2462, or you can email at support@pdmb.com.